

## REBOUND ACE IMPACT REPAIR SPECIFICATION

### Impact Colorcoat WB over damaged Impact finishes

#### Step 1 :

Sand surface with a medium grade sanding pad.

#### Step 2 :

Scrub surface with scrubber/detergent with bristle pad attached to remove all loose and friable material

#### Step 3 :

Once all loose unbound material has been removed, application can proceed.

#### Application :

Mix the **Impact Colorcoat WB** with **Impact Colorcoat Catalyst** (250ml per 20 litre drum), by thoroughly mixing with a drill stirrer.

**NB : MIX ONLY SUFFICIENT PRODUCT REQUIRED FOR USE IN FORTHCOMING 24 HOUR PERIOD AS CATALYST CEASES TO BE ACTIVE AFTER 24 HOURS ALTHOUGH PRODUCT REMAINS USEABLE.**

Transfer all material to another drum, scraping the sides to ensure all material is transferred. Remix thoroughly.

Apply product as per usual maintaining wet edge for seamless application.

Apply second coat the next day prepared as per the first.

A mixed drum has a pot life of 24 hours so product from the first application can be used. (Re-stir before use).

#### Linemarking:

Mix line marking with catalyst – 4lt bucket of **Impact Linemarking** requires 50ml of **Impact Linemarking Catalyst**.

Mix as per Impact Colorcoat WB.

Apply line marking using standard procedure. Edging tape must be removed while line marking is still wet, otherwise line marking will stick to the edging tape and sheet off on tape removal.

Product can be walked on next day but should be allowed to cure for at least 7 days before court use or cleaning.