

## REBOUND ACE IMPACT INSTALLATION SCHEDULE GUIDE

PROCESS	No. of Men for Process	No. of Days for Process				
		(including curing)				
		1 Court	2 Courts	3 Courts	4 Courts	6 Courts
1. Site set up/surface preparation	2	1	2	2	3	4
2. Adhesive/base mat	5	0.5	1	3	4	6
3. WB Mat Sealer	2	0.5	1	1	2	3
4. High Impact Liquid	5	0.5	1	1.5	2	3
5. Sand/Grind Ridges/Repair Airholes	2	0.5	0.5			
6. Topcoat	2	1	2	2	2	3
7. Linemarking *	2	1	1	2	3	3
8. Site Clean up (progressive)	1	0.5				
<b>Sub Total days</b>		<b>6</b>	<b>12</b>	<b>16</b>	<b>16</b>	<b>22</b>
<b>Number of man days</b>		<b>22</b>	<b>50</b>	<b>50</b>	<b>70</b>	<b>98</b>
<b>25% bad weather allowance</b>		<b>5</b>	<b>9</b>	<b>12</b>	<b>18</b>	<b>25</b>
<b>Total man days</b>		<b>27</b>	<b>46</b>	<b>62</b>	<b>88</b>	<b>123</b>

\* Dependant on the number of lines, however, as a general rule - one colour per day.